
MSTC, RS, & CMST STRAPS IN FIELD BENT APPLICATIONS


USP recently conducted research to investigate the capacity of a field bent strap creating a bearing area (see drawing below). Published in the table below are capacities for some of our strap and coil strap products using a predefined bearing area and fastening schedule. Using this application will assist the responsible designer in reducing the number of different products used on a project.

Simply bend a section of the strap over a rigid corner such as an edge of concrete. Trim the horizontal leg of the strap as needed for a finished edge. It is permissable to make one complete bend on the strap. The bend shall be a clean, sharp 90 degree bend. **Important:** Additional bending may reduce the capacity of the strap.




Installation:

- Use all specified fasteners.
- Bend strap only once.



Front View



Bearing Area

Side View

		Dimensions		Fastener Schedule			Allowable Loads (Lbs.) ^{2,3}
USP	Steel		L				DF-L / SP
Stock No.	Gauge	W	Min.4	Stud	Bottom	Face	160%
Flat Strap							
MSTC40	16	3	22	(28) 10d	(4) 10d	(12) 10d	3110
MSTC66	14	3	28	(36) 10d	(4) 10d	(12) 10d	4110
Coil Strap							
RS150	16	1-1/4	10	(12) 10d	(3) 10d	(7) 10d	1300
CMSTC16	16	3	22	(28) 10d	(4) 10d	(12) 10d	3110
CMST14	14	3	32	(36) 10d	(4) 10d	(12) 10d	4110

- 1) Minimum 3" length for bearing flange.
- 2) Allowable loads apply to DF-L/SP. For S-P-F multiply allowable loads by 0.861.
- 3) Allowable loads have been increased 60% for wind and seismic loads; no further increase shall be permitted.
- 4) L Min. is the minimum strap length required against the wall stud above the sill plate.



USP supplies quality products to build Stronger Safer Structures

Customer Service: Burnsville, MN Phone: 1-800-328-5934/ 1-952-898-8772 Fax: 1-952-898-8605

Manufacturing: Montgomery, MN Livermore, CA Largo, FL Thornhill, Ontario

Warehouses: Corona, CA Humble, TX Lumberton, NJ