

Description	MiTek Stock No.	Ref. No.	Steel Gauge	H (in)	Fastener Schedule ³					DF/SP				S-P-F			
					Supporting Member		Supported Member			Allowable Loads (Lbs.) ²				Allowable Loads (Lbs.) ²			
							per Hip	per Jack		Floor	Roof		Uplift ¹	Floor	Roof		Uplift ¹
					Qty	Type	Qty	Qty		100%	115%	125%	160%	100%	115%	125%	160%
2 x 6 right / left	HJC26	LTHJA26, THJA26, THJU26	12	5-3/8	16	16d	5	7	10d	2750	3055	3265	2345	2420	2685	2750	1905
2 x 8 right / left	HJC28	--	12	7-1/8	20	16d	6	8	10d	3385	3385	3385	2345	2760	2760	2760	1910
2 x 6 terminal	HHC26	LTHJA26, THJA26	12	5-7/16	20	16d	5	--	10d	3100	3505	3505	2130	2725	2800	2800	1870
2 x 8 terminal	HHC28	--	12	7-3/16	24	16d	6	--	10d	3505	3505	3505	2410	2805	2805	2805	1930
2 x 6 terminal	HJHC26	--	12	5-7/16	20	16d	5	2	10d	3100	3505	3505	2410	2725	2815	2815	1935
2 x 8 terminal	HJHC28	--	12	7-3/16	24	16d	6	2	10d	3505	3505	3505	2410	2820	2820	2820	1940
2 x 6 terminal	HTHJ26-18	--	18	5	16	16d	7	5	16d	2295	2605	2695	1790	1985	2110	2110	1225

1) Uplift loads have been increased 60% for wind or seismic loads; no further increase shall be permitted.

2) Table values are the total load of hip/jack combined, and assume that the allowable download and uplift of a single member are no more than 75% of the total hanger capacity.

3) **NAILS:** 10d nails are 0.148" dia. x 3" long, 16d nails are 0.162" dia. x 3-1/2" long.